

Installing Ottobock Drivers from Ottobock Website

This guide can be used when installing 60X5/60X1 drivers on Windows 8, Windows 7, or Windows XP.


Driver Installation

Click the following link and save the drivers to your desktop:


http://academy.ottobockus.com/software/Drivers/USB_DRIVERS_3.0.exe

After saving the drivers to your desktop, double click the **USB_DRIVERS_3.0.exe** file to unzip the drivers and start the installation process.

If prompted with the following security message, click **Run**.




Click **Yes** if prompted with the following message:




Plug the 60X5/60X1 adapter into the computer.

- Click **Next** on the welcome screen.



- During the installation you may be prompted several times with a security message similar to the following screenshots. If you are prompted with this message, click **Install this driver software anyway** on Windows 7 or **Continue Anyway** on Windows XP.



Windows 7



Windows XP

- Click **Finish**. The 60X5/60X1 drivers are installed!

